



# EWELLIX Linear Actuators

## CAP

User Manual



# Contents

1	About the manual.....	4
1.1	Information in this user manual.....	4
1.2	Symbols .....	4
1.3	Signs.....	4
1.4	Legal notices .....	4
1.5	Liability.....	5
1.6	Availability .....	5
1.7	Images .....	5
2	General safety regulations .....	5
2.1	Intended Use.....	5
2.2	Non-intended Use .....	6
2.3	Qualified personnel.....	6
2.4	Protective equipment .....	6
2.5	Hazards.....	7
2.6	Safety regulations.....	7
2.6.1	Commissioning.....	7
2.6.2	Operation .....	7
2.6.3	Transport and storage.....	8
2.6.4	Maintenance and Repairs .....	8
3	Scope of delivery.....	8
3.1	Check for transport damage.....	8
3.2	Check for defects .....	8
4	Product description.....	8
4.1	Attachment Options.....	9
5	Transport and storage .....	9
6	Mounting .....	10
6.1	CAP32 installation.....	11
6.2	CAP43A, CAP43B installation.....	12
7	Commissioning .....	12
8	Operation .....	13
9	Troubleshooting .....	13
10	Maintenance .....	13
11	Disposal .....	14
12	Technical data .....	14
12.1	Duty Factor .....	15
12.2	Circuit Diagrams .....	17
13	Replacement parts .....	18

# 1 About the manual

## 1.1 Information in this user manual

This manual provides important information on how to work with the device safely and efficiently.

The manual is part of the device, must always be kept in the device's direct proximity and should be available for personnel to read at any time. All personnel working with the device must read and understand this manual before starting any work. Strict compliance with all specified safety notes and instructions is a basic requirement for safety at work.

Moreover, the accident prevention guidelines and general safety regulations applicable at the place of use of the device must also be complied with.

## 1.2 Symbols

Safety precautions are identified by symbols and signal words as shown. The signal words indicate the severity of the hazard and the chance it could occur. Follow these safety precautions and act cautiously in order to avoid accidents, personal injury and damage to property.

The warning and hazard symbols are defined in accordance with ANSI Z535.6-2011.

### 1 Warning and hazard symbols

#### Signs and descriptions

<b>DANGER</b>	In case of non-compliance, death or serious injury will occur.
<b>WARNING</b>	In case of non-compliance, death or serious injury may occur.
<b>CAUTION</b>	In case of non-compliance, minor or slight injury may occur.
<b>NOTICE</b>	In case of non-compliance, damage or malfunctions in the product or the adjacent construction may occur.

## 1.3 Signs

The warning, prohibition, and mandatory signs are defined in accordance with DIN EN ISO 7010 or DIN 4844-2.

### 2 Warning, prohibition, and mandatory signs

#### Signs and descriptions

	General warning
	Electrical voltage warning
	Observe the manual
	General mandatory sign

## 1.4 Legal notices

The information in this manual reflects the status at the time of publication.

Unauthorized modifications to or improper use of the product are not permitted. Schaeffler accepts no liability in these cases.

## 1.5 Liability

In any case, the owner or the operator of the device is liable for its proper functioning if the device is improperly installed, maintained or repaired by persons who are not part of the Schaeffler Service department, or if the device is used in a manner that does not correspond to its intended use.

Schaeffler shall not be liable for any damage resulting from failure to observe these instructions. These instructions are not to be considered as an extension of the warranty and liability conditions set out in Schaeffler's Terms and Conditions of Sale and Delivery.

The product is not subject to labeling requirements according to CE Directives or EMC Directives. The required EMC measures must be implemented on the end product by the manufacturer of the end product, taking into account the installation conditions, wiring and control, and must be checked in accordance with the intended use.

Compliance with these regulations is the responsibility of the manufacturer of the machine or system.

## 1.6 Availability



A current version of these instructions is available at:  
<https://www.schaeffler.de/std/2225>



Ensure that this manual is always complete and legible and is available to all persons engaged in transporting, fitting, dismantling, commissioning, operating, or maintaining the product.

Keep the manual in a safe place for immediate reference.

## 1.7 Images

The images in this manual may be schematic representations and may differ from the delivered device.

# 2 General safety regulations

## 2.1 Intended Use

The actuator is only intended for use in the following situations:

- Axial loads
- Indoor applications
- Ambient temperature range from -20 °C to +50 °C (-5 °F to +122 °F)
- Intermittent use

Actuators using one of the following motor series may only be used in an industrial environment.

- D12
- P24

These actuators comply with the emission requirements of EMC generic standard EN 61000-6-4, Emission standard for industrial environments.

The user may need to take suitable measures with regard to emissions if the product is operated in residential, commercial, and light industrial environments in accordance with EMC generic standard EN 61000-6-3.

## 2.2 Non-intended Use

The device must not be operated in potentially explosive atmospheres.

Do not use the device to lift people.

## 2.3 Qualified personnel

Operator duties:

- Ensure that only qualified and authorized personnel carry out the activities described in these instructions.
- Ensure that personal protective equipment is used.

Qualified personnel meet the following criteria:

- Product knowledge, e.g. by receiving training on how to use the product
- are fully familiar with the contents of this manual and, in particular, with all of the safety instructions
- are familiar with the relevant country-specific regulations

## 2.4 Protective equipment

For certain work on the product, suitable protective equipment must be worn. Personal protective equipment consists of:

### 3 Required personal protective equipment

Personal protective equipment	Mandatory signs in accordance with DIN EN ISO 7010
Protective gloves	
Safety shoes	
Eye protection	

## 2.5 Hazards

### Danger to life caused by electric current

Touching live parts poses an immediate danger to life. Damage to insulation or individual components can also pose a danger to life. Therefore, observe the following:

- Work on the electrical system may only be carried out by electrically skilled persons.
- Disconnect the system from the power supply before performing any work on the electrical system.
- Before maintenance, cleaning, or repair work, disconnect the power supply and secure it against reconnection.

### Property damage due to exceeded load limit

- Only operate the actuator within the specified load limits

### Property damage due to load

- Always apply load to the actuator centrally
- Only operate the actuator within the specified load limits

### Property damage due to overheating

- Reduce time running under load
- Extend rest time

## 2.6 Safety regulations

The following safety regulations must be observed when working with the product. You can find further information on dangers and specific instructions in other chapters, including those entitled Installation, Commissioning, Operation, and Maintenance.

### 2.6.1 Commissioning

Only qualified personnel may start up the system.

Disconnect the power supply to the drive before performing installation or maintenance work.

Ensure that the drive is not under load or voltage before installation or maintenance work is performed.

Use suitable safety equipment when installing or maintaining the drive.

The power supply must comply with the technical specifications ►14|12.

### 2.6.2 Operation

Exceeding the load limits of the actuator is prohibited. This can lead to serious injuries and material damage. The load limits specified in the technical data need to be observed ►14|12.

Avoid moving the actuator to the mechanical end position. Repeatedly moving the actuator to the mechanical end position can damage it or shorten its operating life.

The motor and surrounding components can become hot under high loads and during a high duty cycle.

Do not operate the brake separately when the actuator is under load.

### 2.6.3 Transport and storage

The product may only be transported and stored in its original packaging and under the permissible ambient conditions, see *Technical data*.

### 2.6.4 Maintenance and Repairs

Maintenance work and repairs may only be carried out by qualified personnel.

Disconnect the power supply to the drive before performing installation or maintenance work.

Ensure that the drive is not under load or voltage before installation or maintenance work is performed.

Use suitable safety equipment when installing or maintaining the drive.

## 3 Scope of delivery

- Actuator
- User manual
- optional: motor
- optional: attachment

### 3.1 Check for transport damage

1. Check the product immediately upon delivery for any damage during transit.
2. Report any damage during transit promptly as a complaint to the carrier.

### 3.2 Check for defects

1. Check the product immediately upon delivery for any visible defects.
2. Report any defects promptly to the distributor of the product.
3. Do not put damaged products into operation.

## 4 Product description

EWELLIX linear actuators CAP are based on the existing modular CAT and CAR range and are coupled with a potentiometer so therefore provide absolute position feedback.

The linear actuators are equipped with a ball screw drive.

Linear actuators offer optional incremental and absolute position feedback to ensure precise motion control. They are highly efficient and lubricated for their entire operating life, thereby providing long-term savings with regard to energy and maintenance. Their robust and compact design is also corrosion-resistant, making them ideal for use in harsh environments.

The CAP32 actuator is available in the following designs:


- DC: 12 V, 24 V
- AC: 120 V, 230 V
- 2 types of front attachment
- 2 types of rear attachment
- Equipped with limit switch

The CAP43A and CAP43B actuators are available in the following designs:

- DC: 24 V
- AC: 230 V
- 2 types of front attachment
- 2 types of rear attachment

## 4.1 Attachment Options

1 Attachment options



001C34D1

1	Front attachment, clevis 576-32	2	Safety pin for 576-32
3	Lock nut M12	4	Front attachment, rod end 575-32
5	Actuator front attachment G3	6	Actuator front attachment G5
7	Actuator front attachment G4	8	Actuator front attachment G1/G2
9	Actuator rear attachment A1/ A2	10	Actuator rear attachment K1/ K2
11	Mounting rod	12	Safety pin
13	Rear attachment, single bracket 580-32	14	Rear attachment, universal connection 582-32

## 5 Transport and storage

Observe the safety regulations for transport.

Observe the safety regulations for the storage.


## 6 Mounting

The surface the actuator is attached to must be able to withstand the force exerted by the actuator.

**!** If the actuator is ordered without a motor, make sure that the maximum dynamic torque on the worm screw does not exceed 0.3 Nm.

When attached, the maximum angle between the actuator and the rear attachment must not exceed 30°.

② Maximum admissible attachment angle




001C33F3

a	°	Max. admissible attachment angle 30°
F	N	Force

Make sure that the force exerted on the attachments is always centered on the actuator.

③ Force applied to the actuator always centered




001C33F5

F	N	Force
---	---	-------

## 6.1 CAP32 installation

### 4 CAP32 installation




001C34E1

1	Front attachment, clevis 576-32	2	Safety pin for 576-32
3	Lock nut M12	4	Front attachment, thread
5	Actuator rear attachment A1/A2	6	Mounting rod
7	Retaining ring	8	Rear attachment, single bracket 580-32

1. Screw the lock nut (3) onto the actuator front attachment (4).
2. Screw the front attachment (1, 2) onto the actuator front attachment (4). The engaging thread length must be at least 12 mm, which is the diameter of the thread.
3. Tighten the front attachment (1) with the lock nut (3) to 20 Nm.
4. Remove the safety pin (2) from the front attachment (1).
5. Install the actuator onto the front and rear attachments. Mount the safety pin (2) onto the front attachment (1). Mount rod (6) with retaining rings (7) onto the rear attachments (5) and (8)

## 6.2 CAP43A, CAP43B installation

### 5 CAP43A and CAP43B installation



001C34F1

1	Front attachment, clevis 576-32	2	Safety pin for 576-32
3	Lock nut M12	4	Front attachment, thread
5	Actuator rear attachment A1/ A2	6	Mounting rod
7	Safety pin	8	Rear attachment, single bracket 580-32

1. Screw the lock nut (3) onto the actuator front attachment (4).
2. Screw the front attachment (1, 2) onto the actuator front attachment (4). The engaging thread length must be at least 12 mm, which is the diameter of the thread.
3. Tighten the front attachment (1) with the lock nut (3) to 20 Nm.
4. Remove the safety pin (2) from the front attachment (1).
5. Install the actuator onto the front and rear attachments. Mount the safety pin (2) onto the front attachment (1). Mount rod (6) with safety pins (7) onto the rear attachments (5) and (8)

## 7 Commissioning

Only qualified personnel may start up the system.

The power supply must comply with the technical specifications ►14 | 12.

1. Disconnect the power supply for the actuator before installation.
2. Make sure that the actuator is not under load or voltage.
3. Use suitable safety equipment.

## 8 Operation

 Avoid moving the actuator to the mechanical end position. Repeatedly moving the actuator to the mechanical end position can damage it or shorten its operating life.

### WARNING



#### Load limit exceeded

Risk of injury

- Observe the load limits specified in the technical data.

### NOTICE



#### Load limit exceeded

Material damage to the actuator

- Observe the load limits specified in the technical data.

The motor and surrounding components can become hot under high loads and during a high duty cycle.

Do not operate the brake separately when the actuator is under load.

## 9 Troubleshooting

### WARNING



#### Live components

Risk of injury due to electric shock

- Disconnect the devices from the supply voltage before carrying out any work on the drive or control system.

### 4 Malfunction

Malfunction	Possible cause	Remedy
Greatly increased running noises	Motor, actuator, or nut defective	<ul style="list-style-type: none"> <li>Stop operation immediately.</li> <li>Send the actuator to Schaeffler immediately.</li> </ul>
Wobbling actuator movement	Excessive load	<ul style="list-style-type: none"> <li>Stop operation immediately.</li> </ul>

If a malfunction cannot be rectified with the measures described, contact Schaeffler Service.

## 10 Maintenance

Maintenance work and repairs may only be carried out by qualified personnel.

- Disconnect the power supply for the actuator before maintenance work and repairs.
- Make sure that the actuator is not under load or voltage.
- Use suitable safety equipment.

### DANGER



#### Risk of fatal injury from unauthorized reconnection of the power supply

Risk of fatal injury to persons in the hazard area due to moving parts or electric shock if the power supply is switched on without authorization during work on the system and causes the system to restart.

- Before starting work, switch off the system and secure it against reconnection.

### 5 Maintenance plan

Activity	daily	monthly	every 6 months	annually
Check the device for visible damage	✓			
Remove any dust and dirt	✓			
Check attachments and tighten them if necessary		✓		
Check cables for damage and replace them if necessary		✓		
Check special equipment for visible damage and replace it if necessary		✓		
Functional test		✓		
Add a few drops of oil to the adjustment tube			✓	
Check labels				✓
Check electrical connections				✓

## 11 Disposal

Observe the local regulations for disposal.

As the actuator is principally made of steel and stainless steel, it may have some grease or oil inside. When disposed of, the motor and some accessories – such as limit switches and encoders – are treated as electronic scrap.

## 12 Technical data

All values for standard actuators are tested under the following conditions:

- Temperature +20 °C (+68 °F)
- Stabilized voltage
- Compression load

### 6 Technical data, CAP, DC versions

Characteristic	Unit	CAP32		CAP43A	CAP43B
Voltage supply	–	DC		DC	DC
Voltage	V	12	24	24	24
Current consumption	A	13	8	9	9
			5 <sup>1)</sup>	5	5 <sup>2)</sup>
Type of protection	–	IP20, IP44		IP44	IP44
Rated push load	N	1000 ... 3500		1000 ... 3000	1500 ... 4000
Rated pull load	N	1000 ... 3500		1000 ... 3000	1500 ... 4000
Speed (full load no load) <sup>3)</sup>	mm/s	5 ... 60		5 ... 52	5 ... 65
Stroke S	mm	50 ... 700		100 ... 400	50 ... 700
Retracted length L <sup>4)</sup>	mm	S + 301		S + 150 / 158 / 189	S + 167 / 175 / 206
Power consumption	W	–		–	–
Duty cycle	%	25		15	20
Ambient temperature	°C	–20 ... +50		–20 ... +50	–20 ... +50
Weight	kg	2.9 ... 5.0		2.0 ... 2.7	2.0 ... 2.7

<sup>1)</sup> for motor D24CW and P24CW

<sup>2)</sup> for motor C24CW, D24CW and P24CW

<sup>3)</sup> Depending on the motor selected

<sup>4)</sup> Depending on the front attachment selected

## 7 Technical data, CAP, AC versions

Characteristic	Unit	CAP32		CAP43A	CAP43B
Voltage supply	-	AC		AC	AC
Voltage	V	120	230	230	230
Power consumption	W	98	92	92	92
Power consumption, braking	W	133.2	117.3	117.3	117.3
Current consumption	A	0.82	0.4	0.4	0.4
Current consumption, braking	A	1.11	0.51	0.51	0.51
Type of protection	-	IP20, IP54		IP54	IP54
Rated push load	N	1500 ... 3500		1000 ... 3000	1000 ... 3500
Rated pull load	N	1500 ... 3500		1000 ... 3000	1000 ... 3500
Speed (full load to no load) <sup>5)</sup>	mm/s	6 ... 32		5 ... 20	5 ... 20
Stroke S	mm	50 ... 700		100 ... 400	50 ... 700
Retracted length L <sup>6)</sup>	mm	S + 301		S + 150 / 158 / 189	S + 167 / 175 / 206
Duty cycle	%	30		20	20
Ambient temperature	°C	-20 ... +50		-20 ... +50	-20 ... +50
Weight	kg	2.9 ... 5.0		2.6 ... 2.8	2.6 ... 2.8

<sup>5)</sup> Depending on the motor selected

<sup>6)</sup> Depending on the front attachment selected

## 12.1 Duty Factor

The permissible load depends on the duty factor, i.e., the load must be reduced if the duty factor is increased. The duty factor is defined as the time running under load in relation to the total cycle time.

### f11 Determining the duty factor

$$D = \frac{N}{N+R} \cdot 100$$

D	%	Duty factor
N	s	Time running under load
N+R	s	Total cycle time
R	s	Rest time

### NOTICE




#### Duty factor exceeded

Material damage to the actuator due to overheating

- Reduce running under load
- Extend rest time

### 6 Definition of duty factor



001C33F0

N	s	Time running under load
N+R	s	Total cycle time
R	s	Rest time

## DC versions

The admissible load for DC actuators at a given duty cycle is expressed as a percentage of the maximum dynamic load-carrying capacity

8 Duty factor for DC versions at +20 °C (+68 °F)


Actuator	Max. duty factor at max. dynamic load
CAP32	25 %
CAP43A	20 %
CAP43B	20 %

## AC versions

The diagrams show the maximum load as a function of the duty cycle.


The diagrams show the required capacitor size at different loads and duty factors.

7 CAP32 AC version: admissible load




001C33E5

8 CAP43A AC version: admissible load



001C33E7

□ 9 CAP43B AC version: admissible load




001C33E5

## 12.2 Circuit Diagrams


Complete installation instructions for the limit switch can be found in the separate installation instructions.

□ 10 AC: 230 V



001D2216


□ 11 DC: 12 V, 24 V



001D2226


## Potentiometer

12 Wiring diagram for linear potentiometer



001D2236

13 Wiring diagram for rotating potentiometer



001D2246

## 13 Replacement parts

If you require additional information or spare parts, please contact Schaeffler.



**Schaeffler Technologies AG & Co. KG**  
Georg-Schäfer-Straße 30  
97421 Schweinfurt  
Germany  
[www.schaeffler.de/en](http://www.schaeffler.de/en)   
[info.de@schaefller.com](mailto:info.de@schaefller.com)

In Germany:  
Phone 0180 5003872  
From other countries:  
Phone +49 9721 91-0

All information has been carefully compiled and checked by us, but we cannot guarantee complete accuracy. We reserve the right to make corrections. Therefore, please always check whether more up-to-date or amended information is available. This publication supersedes all deviating information from older publications. Printing, including excerpts, is only permitted with our approval.  
© Schaeffler Technologies AG & Co. KG  
BA 126 / 01 / en-US / 2025-12