



Condition monitoring system

FAG OPTIME E-CM

User Manual

We pioneer motion

SCHAEFFLER

Contents

1	About the manual.....	5
1.1	Information in this operating manual	5
1.2	Symbols	5
1.3	Signs.....	5
1.4	Legal guidelines.....	5
1.4.1	Advice on third party products and services	6
1.4.2	Other applicable documents, certificates and licences.....	6
1.5	Limitation of liability.....	6
1.6	Availability	7
1.7	Images	7
2	General safety regulations	8
2.1	Usage for the intended purpose	8
2.2	Usage not for the intended purpose	8
2.3	Warranty.....	8
2.4	Qualified personnel.....	8
2.5	Safety regulations.....	9
2.5.1	Work on electrical devices.....	9
2.5.2	Safety during installation	9
2.5.3	Safe handling of information interfaces	9
2.5.4	Protection against unauthorised use	10
3	Product description.....	11
3.1	Control elements and LED displays.....	13
4	Scope of delivery.....	15
4.1	Required accessories	16
5	Assembly.....	18
5.1	Guidelines for assembly	18
5.2	Mechanical design.....	18
5.3	Electrical connections	18
5.3.1	Connecting to the power.....	19
5.3.2	Connecting the voltage inputs	19
5.3.3	Installation of current sensors	21
5.3.4	Completing the installation.....	22
6	Commissioning	23
6.1	Configuration.....	23
6.1.1	Communication interfaces.....	23
6.2	Set up the device via the web configurator	23
6.3	Provisioning the device in the OPTIME mobile app.....	25
6.4	OPTIME Online Help.....	26
7	Maintenance	27
8	Disassembly	28
9	Disposal	29

10	Technical information	30
10.1	Connection diagrams.....	30
10.1.1	3-phase installation.....	30
10.1.2	3-phase installation with neutral wire	30
10.1.3	Double 3-phase installation	31
10.2	Technical specifications	32
10.3	Type plate	34
10.4	Abbreviations for measured values	34
11	Declaration of Conformity.....	35
11.1	Declaration of Conformity.....	35
11.1.1	FCC Statement	35
11.1.2	ISED Declaration of Conformity.....	35
12	Manufacturer details.....	36

1 About the manual

1.1 Information in this operating manual

This manual enables safe and efficient handling of the device.

Personnel must have carefully read and understood it before starting any work. A basic prerequisite for safe working is compliance with all the safety information and instructions in this manual.

In addition, the local accident prevention regulations and general safety regulations applicable to the device's area of use must be used.





1.2 Symbols

Safety information is marked by symbols in this manual. The safety information is introduced by signal words that indicate the severity of the hazard. To avoid accidents, personal injury and damage to property, always observe the safety information and act with caution.

The warning and hazard symbols are defined in accordance with ANSI Z535.6-2011.

1.1 Warning and hazard symbols

Signs and descriptions





 DANGER	In case of non-compliance, death or serious injury will occur.
 WARNING	In case of non-compliance, death or serious injury may occur.
 CAUTION	In case of non-compliance, minor or moderate injury may occur.
 NOTICE	In case of non-compliance, damage or malfunctions in the product or the adjacent construction may occur.

1.3 Signs

The warning, prohibition and mandatory signs are defined in accordance with DIN EN ISO 7010 or DIN 4844-2.

1.2 Warning, prohibition and mandatory signs

Signs and descriptions

	General warning
	Electrical voltage warning
	Observe the manual
	General mandatory sign

1.4 Legal guidelines

The information in this manual reflects the status at the time of publication.

Unauthorised modifications to or improper use of the product are not permitted. Schaeffler accepts no liability in these cases.

Apps and functions may not be available in all countries and regions. The availability of apps and functions may change.

Further information, in particular on the OPTIME Mobile App and the OPTIME Dashboard, is available in the OPTIME Online Help in the OPTIME Dashboard. The Online Help is continuously updated.

Further information, particularly regarding the Power-Cloud, can be obtained from:

support@eco-adapt.com

1.4.1 Advice on third party products and services

All names of products and services cited in this manual are brand names of the respective companies. The details provided in the text are merely indicative and provided for information purposes only.

- Apple, App Store, Safari and their logos are registered trademarks of Apple Inc.
- Google, Android, Google Play, Google Chrome and their logos are registered trademarks of Google LLC.
- Microsoft, Windows, Edge, Internet Explorer, Excel and their logos are registered trademarks of the Microsoft Corporation
- Mozilla, Mozilla Firefox and their logos are registered trademarks of the Mozilla Foundation
- Wirepas, Wirepas Mesh and their logos are registered trademarks of Wirepas Ltd.
- Modbus is a registered trademark of the Modbus Organization
- BACnet is a registered trademark of ASHRAE
- Wi-Fi is a registered trademark of the Wi-Fi Alliance

The information given in this publication cannot be construed as constituting any related liability for products and services not produced or provided by Eco-Adapt SAS and Schaeffler Technologies AG & Co. KG. Eco-Adapt SAS and Schaeffler Technologies AG & Co. KG do not assume ownership of these products and services.

Other product and manufacturer names cited in this publication may be the trademarks of their respective owners.

1.4.2 Other applicable documents, certificates and licences

Licence information

The firmware of the FAG OPTIME E-CM product uses open source libraries under the GNU General Public Licence (GPL) to provide certain functionalities of the product according to the requirements of GPL version 2 (section 3b) and version 3 (section 6b). For more information on the libraries used, including their respective license terms, see the FAGOPTIME E-CM web configurator menu under [Show open source licences].

GPL written offer

Eco-Adapt SAS provides the applicant, upon request, with machine-readable source code from the libraries used under the GPL for at least three years from the delivery date of the FAG OPTIME E-CM device.

1.5 Limitation of liability

All information and instructions in this manual have been compiled in accordance with the applicable standards and regulations, the current state of the art, and our many years of knowledge and experience.

The manufacturer shall not be liable for any damage resulting from:

- failure to observe this manual
- any use other than the intended purpose
- employment of untrained personnel
- unauthorised conversions
- technical modifications
- use of non-approved spare parts

In the event of customer-specific adjustments, the product that is actually delivered may differ from the description in this manual. In such cases, please contact Schaeffler to obtain further instructions or safety precautions for these devices.

We reserve the right to make technical modifications to the device to improve the user experience.

1.6 Availability



A current version of this manual is available at:

<https://www.schaeffler.de/std/2235>

Ensure that this manual is always complete and legible and is available to all persons engaged in transporting, fitting, dismantling, commissioning, operating or maintaining the product.

Keep the manual in a safe place for immediate reference.

1.7 Images

The images in this manual may be schematic representations and may differ from the delivered device.

2 General safety regulations

2.1 Usage for the intended purpose

The FAG OPTIME E-CM condition monitoring system is approved for use in indoor industrial environments. The FAG OPTIME E-CM condition monitoring system may only be used in accordance with the technical data. Unauthorised structural modifications to the system are not permitted. We assume no liability for any damage to machinery or injury to persons arising from such actions.

Intended use also includes the following:

- compliance with all instructions in the user manual
- compliance with all relevant specifications on occupational safety and accident prevention throughout the entire product life cycle of the system
- possession of the required specialist training and authorisation from your company to carry out the necessary work on the system

2.2 Usage not for the intended purpose

The OPTIME condition monitoring system does not provide machine protection and must not be used as a component of safety-related systems.

The OPTIME condition monitoring system is not classified as a safety component in accordance with Machinery Directive 2006/42/EG.

The same applies to the Power-Cloud system from Eco-Adapt SAS.

2.3 Warranty

The manufacturer provides warranty in relation to operational safety, reliability and performance only under the following conditions:

- The product may only be mounted and connected by authorized technical personnel.
- The system must be used in accordance with the information in the technical data sheets. The limit values indicated in the technical data must not be exceeded under any circumstances.
- Modifications and repairs to the system may only be performed by the manufacturer.

2.4 Qualified personnel

Obligations of the operator:

- Ensure that only qualified and authorised personnel perform the activities described in this manual.
- Ensure that personal protective equipment is used.

Qualified personnel must:

- Ensure adequate product knowledge, e.g. through training on proper handling and use of the product
- be fully familiar with the contents of this manual, particularly all safety instructions
- be aware of any relevant country-specific regulations

2.5 Safety regulations

This section summarises the most important safety regulations for working with the FAG OPTIME E-CM condition monitoring system.

2.5.1 Work on electrical devices

Work on the electrical assemblies may only be carried out by a qualified electrician.

Damaged components of the system must not be repaired. Any necessary repair work must be carried out by Schaeffler .

A defective connection cable must be replaced immediately by a qualified electrician.

Wiring, opening and closing of electrical connections may only be performed when the system is disconnected from the power supply and in a voltage-free state.

2.5.2 Safety during installation

Before installation, the components must be checked for external damage. If any damage or other defects are found, the system must not be commissioned.

Only qualified personnel may commission the system.

2.5.3 Safe handling of information interfaces

This product has the following information interfaces:

- 4G mobile network
for full data transmission
- Ethernet (Modbus TCP or BACnet/IP)
for partial data transmission
- RS 485
for partial data transmission

This product has the following information interface for the electrical set-up:

- Wi-Fi
for data transmission during electrical set-up

With the exception of the LTE interface, the product can be connected to other devices, components or to internal trusted networks via the aforementioned interfaces. Devices such as data carriers that are connected via information interfaces may contain malware or execute harmful functions undetected. The use of such information interfaces can damage this product or potentially the company infrastructure, e.g. IT infrastructure. In addition, the use of such interfaces may compromise your company's data security.

Before using our product and its information interfaces, please familiarise yourself with the following points:

- the safety precautions offered by the product and its information interfaces
- the security provisions of your company, e.g. in relation to IT security

Before commissioning, please clarify with your relevant points of contact whether, and which, security measures are to be taken when using the product and its associated information interfaces.

2.5.4 Protection against unauthorised use

The FAG OPTIME E-CM system provides security functions that meet the cybersecurity requirements in accordance with EN 18031 as part of the Radio Equipment Directive (RED).

To protect against unauthorised use of the OPTIME cloud, the OPTIME mobile app and the OPTIME dashboard, data encryption and secure login using individual user credentials are implemented.

The Power-Cloud application is also protected by two-factor authentication.

The local configuration of the FAG OPTIME E-CM module is also password-protected.

The default password must be changed during initial installation. Users must log in with a user name and password, and use a secure password. The user is responsible for keeping their login data secure.


3 Product description

FAG OPTIME E-CM is an electrical and mechanical condition monitoring solution for AC-powered rotating machines. This solution enables the monitoring of two 3-phase rotating machines to be monitored.

Any attempt to equip a DC-powered or non-rotating electrical machine with this device is prohibited.

3

1 Connections on the device



001D2140

1	2x 3-phase voltage measurement	2	2x Ethernet ports
3	Power supply	4	2x status LEDs
5	Data Matrix code for device identification	6	Reset button
7	SIM card	8	RS485 port
9	Antenna connection	10	2x connection for RJ45, each for one 3-phase current signal

The FAG OPTIME E-CM generates its own Wi-Fi network to enable quick and easy set-up via a computer or smartphone. You can configure the electrical parameters via the web configurator. Provisioning is carried out using the OPTIME mobile app. During this process, the device type “Electric motor” is created automatically and the required motor parameters are requested. These parameters can also be defined in advance in the OPTIME dashboard’s hierarchy wizard to simplify provisioning.

The measurement data are transmitted to the OPTIME cloud via the 4G mobile network. There, the data are analysed and both the measurement data and analysis results are displayed in the OPTIME dashboard and the OPTIME mobile app.

! Provisioning via the OPTIME mobile app and the OPTIME dashboard is not available to customers of Eco-Adapt SAS and the Power-Cloud.


Further information

OPTIME:

Online help ▶ 26 | 6.4
in the OPTIME dashboard

OPTIME | Ecosystem |
<https://www.schaeffler.de/std/1FFF>

Eco-Adapt SAS and Power-Cloud:
<https://www.eco-adapt.com/download/>



3.1 Control elements and LED displays

The LED indicators of the FAG OPTIME E-CM device are located on the front of the device.

LED activity during system start

As soon as the FAG OPTIME E-CM device is supplied with power, the following LED activity occurs:

1. The SYSTEM LED flashes briefly.
2. Both LEDs light up once briefly.
3. The SYSTEM LED flashes continuously.
4. The SYSTEM LED lights up continuously in green.

3 Boot process

LED		Meaning
System A	Communication B	
Boot process		
Flashes green	Flashes green	Boot process loading.
Flashes green	Off	System loading.
Lights up green	Off	System ready.
Flashes yellow	Off	Emergency mode loading.
Lights up yellow	Off	Emergency mode ready.

4 Operation

LED		Meaning
System A	Communication B	
Operation		
Lights up green	Flashes green	System ready. LTE connection is being established.
Lights up green	Lights up red	System ready. LTE connection could not be established. Retrying connection.
Lights up green	Lights up green	System ready. LTE connection is established.
Lights up green	Off	System ready. LTE connection not available.

5 Firmware update

LED		Meaning
System A	Communication B	
Firmware update		
Flashes green	Flashes yellow	Emergency mode update in progress.
Flashes yellow	Flashes yellow	System update in progress.

If an update fails, e.g. in the event of a power failure, the device will start in emergency mode with limited functions. During an update, it must be ensured that the power supply is not interrupted.

The update can be carried out again via the web configurator. Please contact the relevant technical support.

System reset

Press the reset button for 3 s, if necessary using a straightened paper clip, to restart the device. This resets the password and connectivity information. Other device settings are retained.

Resetting the device to factory settings

Press the reset button for 10 s, if necessary using a straightened paper clip, to reset the device to factory settings.

4 Scope of delivery

- FAG OPTIME E-CM.CPU-2CH:
2-channel electrical and mechanical health monitoring solution for alternating current rotational machines
- Current transformers or Rogowski coils, incl. extension cables suitable for the currents to be measured
- Antenna (standard or high-sensitivity), depending on reception conditions

4

3 Scope of delivery

The diagram illustrates the components included in the scope of delivery for the FAG OPTIME E-CM.CPU-2CH. The main device is shown with its top and front panels. The top panel features two sets of terminal blocks for power supply (U2 and U1) and two Ethernet ports (ETH1 and ETH2). The front panel includes a power button, a Wi-Fi indicator, a QR code, and a serial number (SN: 004eaccb6cb). The bottom panel shows terminals for current transformers (CT1, CT2), an antenna port, and an RS485 port. The accessories are numbered 1 through 5: 1 is the power supply unit, 2 is the antenna, 3 is the Rogowski coils, 4 is the current transformers, and 5 is the extension cable.

1	FAG OPTIME E-CM.CPU-2CH	2	Antenna (standard version or high-sensitivity, depending on reception conditions)
3	Rogowski coils	4	Current transformers
5	Extension cable		

001D2150

4.1 Required accessories

To ensure the system is ready for use, the customer must provide the following devices and accessory parts in addition to the FAG OPTIME E-CM:

- 2-A fuse (circuit breaker) for input signals for voltage measurement and power supply (each input separately)
- Voltage measurement cable and power supply cable (in accordance with the requirements of the voltage range)

WARNING



Safety risks due to non-approved components

Only the accessory parts listed below are approved for use with this device. The manufacturer accepts no liability for damage to property, malfunctions or safety risks resulting from the use of non-approved components.

- Use only the accessories listed in the manual.



For customers of Eco-Adapt SAS who use the Power-Cloud, material numbers and designations are different.

6 Current transformers (CTs)

Ordering number	Designation	Description	Rated current	Inside diameter
			A	mm
301827972-0000-10	OPTIME-E_CM.TRAFO-3CT-1A-10-2,5M	Set with 3 current transformers with split core	1	10
301822131-0000-10	OPTIME-E_CM.TRAFO-3CT_5A-10_2,5M	Set with 3 current transformers with split core	5	10
301822123-0000-10	OPTIME-E_CM.TRAFO-3CT_32A-10_2,5M	Set with 3 current transformers with split core	32	10
301822140-0000-10	OPTIME-E_CM.TRAFO-3CT_70A-10_2,5M	Set with 3 current transformers with split core	70	10
301822158-0000-10	OPTIME-E_CM.TRAFO-3CT_100A-16_2,5M	Set with 3 current transformers with split core	100	16
301822166-0000-10	OPTIME-E_CM.TRAFO-3CT_200A-24_2,5M	Set with 3 current transformers with split core	200	24
301822182-0000-10	OPTIME-E_CM.TRAFO-3CT_400A-36_2,5M	Set with 3 current transformers with split core	400	36

7 Rogowski coils

Ordering number	Designation	Description	Rated current	Inside diameter
			A	mm
306244454-0000-10	OPTIME-E_CM.TRAFO-3RC-3500A-105	Set with 3 current transformers	3500	105

Current transformers (CTs) and Rogowski coils

Unless otherwise indicated, the following specifications apply to all current transformers (CTs) and Rogowski coils:

- maximum voltage (non-insulated conductor): 600 V
- maximum voltage (insulated conductor): depending on the conductor insulation

8 Extension cables for current transformers (CTs) and Rogowski coils as well as antenna accessories

Ordering number	Designation	Description	Length m
301822344-0000-10	OPTIME-E_CM.CAB-EXT-5M	Extension cable for current measurement	5
301822352-0000-10	OPTIME-E_CM.CAB-EXT-10M	Extension cable for current measurement	10
301819742-0000-10	OPTIME-E.ANT-868MHZ-STD_MAG-2,5M	Standard mobile antenna with magnetic fixture, frequencies ▶30 10	2,5
301819750-0000-10	OPTIME-E.ANT-868MHZ-HS_FIX-2,5M	High sensitivity antenna with wall mounting set, frequencies ▶30 10	2,5
301820767-0000-10	OPTIME-E.ANT-868MHZ-HS_MAG-2,5M	High sensitivity antenna with magnetic fixture, frequencies ▶30 10	2,5
301820775-0000-10	OPTIME-E.CAB-EXT_ANT-5M	Antenna extension cable	5
301820783-0000-10	OPTIME-E.CAB-EXT_ANT-10M	Antenna extension cable	10

5 Assembly

⚠ WARNING



Severe or fatal injury due to live components

Failure to observe the safety regulations and the information on assembly can result in a life-threatening electric shock.

- ▶ The device is approved for use indoors only.
- ▶ The device must be installed in a fire-resistant, mechanically and electrically stable housing, e.g. a certified control cabinet.
- ▶ Disconnect the system from the power supply before starting the installation.
- ▶ Use a certified voltage tester to ensure that the installation has been disconnected from the power supply and isolated.

5

5.1 Guidelines for assembly

Observe the following when planning the installation site:

- Reserve a section of at least 6 modules (108 mm) on a 35-mm DIN rail in the control cabinet.
- Ensure that the supplied current transformers (CTs) with 2,5 m cables can be connected to the device following installation.
- If longer distances are required, approved extension cables of up to 10 m must be planned. If no suitable space is available in an existing installation, an additional control cabinet that is equipped with a 35-mm DIN rail must be installed.
- The cables used between the circuit breaker and the voltage input terminals must be designed for 600 V or 1000 V, depending on the wiring type, and must be less than 1,5 m long.
- The screws of the input connections must be tightened to the specified torque ▶32 | 9.


! Make sure there is a sufficient supply of air to maintain the temperature specifications for the device ▶32 | 9.

5.2 Mechanical design

Device installation:

1. Position the device at a slight angle with the upper edge of the rear recess on the DIN rail.
2. Press the device onto the DIN rail until the device clicks into place.

4 Mounting the device



5.3 Electrical connections

A sufficiently long connection cable with the corresponding specifications must be provided for the electrical connection.


5.3.1 Connecting to the power

1. Install the circuit breakers (rated current 2 A) in such a way that the power supply can be safely and easily interrupted at any time.
2. Connect the cables to the 2-pole power supply terminals to supply power to the FAG OPTIME E-CM module ▶19| 5 ▶20| 6 ▶20| 7.


5.3.2 Connecting the voltage inputs

1. Install a circuit breaker (rated current 2 A) in front of the meter for each voltage input used:
 - Position each circuit breaker so that the voltage signal can be safely and easily interrupted.
2. Connect wires L1, L2, L3 from the motor or the machine to the 4-pole voltage input connector. If a neutral conductor is connected to the machine, connect it to the N pin ▶32| 10.2. Observe the connection diagrams ▶19| 5 ▶20| 6 ▶20| 7.
3. If necessary, use the second voltage input connector and separate wiring with a separate circuit breaker if a second machine is to be monitored.


5.3.2.1 3-phase installation



5.3.2.2 3-phase installation with neutral wire



5.3.2.3 Double 3-phase installation



5.3.3 Installation of current sensors

The current can be measured with 2 types of sensors, depending on the maximum current that is expected and the cross-section of the current conductors:

- Split-core current transformers (CTs)
- Rogowski coils

Each group of 3 sensors is connected to one RJ45 input of the FAG OPTIME E-CM device, so that a 3-phase signal can be measured with one RJ45 connection.

The FAG OPTIME E-CM device has 2 RJ45 inputs and can measure 2 3-phase signals in order to monitor 2 different motors or machines.

⚠ WARNING Risk of severe injury or death due to improper assembly

Improper connection of the device may result in life-threatening electric shock and severe damage to the device, connected components and machines.

- Only use approved current transformers and Rogowski coils.
- The RJ45 connections are only intended for transformers that are equipped with internal protection.

NOTICE There is a risk of damage if the connection is incorrect

Connection of a telecommunications network to an RJ45 connector can damage the device.

- Do not connect a telecommunications network to the RJ45 connectors.

NOTICE Malfunction due to incorrect connection

The sequence and orientation of the current transformers, as well as their assignment to the voltage inputs, must be strictly observed. Failure to do so may impair functionality.

- Note the sequence and orientation (printed arrow) of the current transformers and their assignment to the voltage inputs.

5.3.3.1 Use of split-core current transformers (CTs)

1. Attach one current transformer to each phase cable. Install the current transformer so that the arrow printed on it points from the power supply towards the motor.
2. Close the current transformer until 2 clicks are heard to ensure that it is properly closed.
3. Adhere to the correct phase sequence: the current transformers within one RJ45 connection group are numbered from 1 to 3.
4. Secure each current transformer on both sides using cable ties or clamping rings (not included in the scope of delivery).



5.3.3.2 Use of Rogowski coils

1. Place each Rogowski coil around the power conductor and close it.
2. Position the conductor as close as possible to the centre of the coil to ensure an accurate measurement.

9 Rogowski coils



001D205F

5.3.4 Completing the installation

WARNING



Danger to life from electric shock

Improper installation may result in a life-threatening electric shock.

- Observe the installation instructions.
- Carefully check the installation after all work has been completed.

Once the installation is complete, check the following:

- Ensure there is insulation between the various circuits.
- Cables with potentially life-threatening voltages cannot come into contact with the Ethernet ports.
- Terminals L1, L2 and L3 and the external circuits connected to these terminals are neither accessible nor connected to other accessible parts.

6 Commissioning

6.1 Configuration

6.1.1 Communication interfaces

The FAG OPTIME E-CM device supports multiple communication interfaces for configuration, data transfer and system integration. The following options are available:

Using Wi-Fi Direct for local configuration

The device automatically activates its internal Wi-Fi hotspot within 1 min of being switched on:

- Establish a connection to the FAG OPTIME E-CM device using a laptop, tablet or smartphone.

Using the 4G mobile connection

Conditions for transmitting measurement data over the 4G mobile network without an additional configuration:

- Mount the antenna vertically on a horizontal metal surface outside the control cabinet to ensure sufficient signal strength.
- Connect the antenna to the antenna connection of the FAG OPTIME E-CM device.

Using Modbus TCP via Ethernet (reserved for future use)

Conditions for transmitting data via Ethernet using the Modbus TCP protocol:

- Connect the FAG OPTIME E-CM device to the Ethernet network using a standard Ethernet cable.
- Activate Ethernet communication in the configuration menu using the Wi-Fi interface.

Using Modbus RTU via RS485 (reserved for future use)

Conditions for transmitting data via the RS485 interface using the Modbus RTU protocol:


- Connect the communication cables to pins A, B and GND.

6.2 Set up the device via the web configurator

- ✓ The motor must be running under normal operating conditions.
- 1. Connect to the Wi-Fi network of the OPTIME E-CM device.
 - › Wi-Fi designation: OPTIME-E-CM-XXXXXX (last 6 digits of the device serial number (S/N))
 - › Password: optimewifi
- 2. Open the web browser. Enter the address of the web configurator:
 - › <https://optime-e.net/>
- 3. Enter user credentials.
 - › User name: admin
 - › Password: admin
- 4. The application prompts you to change your password.
- 5. Open the [Electrical Setup] menu in the web configurator.

- ⚠ If the password is forgotten, press the reset button for 3 s to restore the device to the default password.

10 Electrical configuration menu



001D8D7D

6. Enter the electrical parameters to complete the configuration.

11 Electrical configuration input mask

001D8D78

7. Enter the required information for the current measurement sensors.
 8. After entering all parameters, select [Validate].
 › The device checks the phase sequence and the polarity of the current measurement sensors.

12 Diagnostics

Check electrical setup

Connector 1
● Last measure: 23.01.2026 15:11:06

Name	Test device CS ch1
Mode	Three-phase
Active power	0,00 W
Active energy	0,00 kWh
Reactive power	0,00 VAR
Reactive energy +	0,00 kVAh
Reactive energy -	0,00 kVAh
Apparent power	0,00 VA
Apparent energy	0,00 kVAh

Details

INFORMATION
COUNTERS

Power factor	0,00		
Frequency	0,00 Hz		
	L1	L2	L3
Current	0,00	0,00	0,00 A
Phase voltage	0,00	0,00	0,00 V
Active power	0,00	0,00	0,00 W
Reactive power	0,00	0,00	0,00 VAR
Apparent power	0,00	0,00	0,00 VA

001D8D7B

9. In the event of errors, follow the instructions in the web configurator.
10. Open the [Live data] menu in the web configurator.
11. Check the real-time measured values (current, voltage, frequency, etc.) for each phase. Check the plausibility of the measured values and compare them with the motor control system values to ensure correct configuration.
12. For standard provisioning, leave the settings under [Communication] and unchanged. Only make adjustments if required for an advanced configuration.

6.3 Provisioning the device in the OPTIME mobile app



Provisioning via the OPTIME mobile app and the OPTIME dashboard is not available to customers of Eco-Adapt SAS and the Power-Cloud.


1. Download the OPTIME mobile app.

13 Download the OPTIME mobile app

001B5450

2. Log in to the OPTIME mobile app using the OPTIME user credentials.
3. In the [Provision sensors] menu, select FAG OPTIME E-CM.
4. Follow the instructions in the OPTIME mobile app.
5. Scan the Data Matrix code on the front of the device.

14 Add the device to the OPTIME mobile app



- !** Create the measurement point for electric motors in advance using the hierarchy assistant in the OPTIME dashboard. All data will then already be available and provisioning in the OPTIME mobile app will be significantly faster. Further information can be found in the OPTIME online help ►26|6.4.

6.4 OPTIME Online Help

Comprehensive explanations on the content and operation of the OPTIME Dashboard are available in the Online Help. The Online Help includes detailed descriptions of the dashboard functions as well as information about the OPTIME Mobile App, the API, training opportunities and support topics. We also keep you informed about our current releases and updates. The Online Help is available in English only.

Accessing the Online Help:

- Log in to the OPTIME Dashboard.
- » The Online Help can be accessed from the menu at the top left of the OPTIME Dashboard start page.

7 Maintenance

The online help in the OPTIME dashboard also contains a list of frequently asked questions (FAQ) that can assist with troubleshooting.

If the problem persists or is not addressed in the FAQ, please contact the relevant technical support.

OPTIME

- EN: www.schaeffler.de/en/technical-support
- DE: www.schaeffler.de/technischer-support

Eco-Adapt SAS and Power-Cloud:


- support@eco-adapt.com

8 Disassembly

To remove the FAG OPTIME E-CM device from the DIN rail, proceed as follows:

1. Ensure that the device is de-energised and that all connections have been decoupled from the device.
2. Place a flat-blade screwdriver at the bottom edge of the module and lever the module upwards (1 and 2).
3. A further lever motion (3) releases the module from the DIN rail.
4. Lift the module upwards and out of the DIN rail (4).

15 Removing the device



001D21A0

1	Position the slotted screwdriver	2	Lever the slotted screwdriver upwards until the device releases from the DIN rail
3	Lever the slotted screwdriver further upwards	4	Lift off the device


9 Disposal

Observe the locally applicable regulations for disposal.


10 Technical information

10.1 Connection diagrams

10.1.1 3-phase installation




10.1.2 3-phase installation with neutral wire



10.1.3 Double 3-phase installation

18 Double 3-phase installation



001DC6FC

1	Frequency converter (optional)	2	Electric motor
3	Machine	4	Device power supply AC 100 V to 480 V, 50 to 60 Hz
5	Circuit breakers, fuse (2 A)	6	FAG OPTIME E-CM device
7	RJ45 cable (Lmax = 10 m)	8	Lmax = 1.5 m (max. distance between circuit breaker and device)

10.2 Technical specifications

9 General

Characteristic	Unit	Value
Dimensions (L × H × W), including connector plug	mm	106,3×106,3×63
Operating conditions		
Ambient conditions	-	Indoors only
Operating temperature	°C	-5 ... +60
Humidity	%	5 ... 90, non-condensing
Degree of contamination	-	2
Maximum altitude	m	2000

10 Power supply

Characteristic	Unit	Value	
Power supply AC N-Ph or Ph-Ph	V	100 ... 480, RMS	
Frequency	Hz	50 or 60	
Overvoltage category	-	CAT III 600 V	
Maximum voltage deviation from rated voltage	%	±10	
Terminal block with 2 connections	Quantity	Piece	1
	Stranded wires 16-12 AWG	mm ²	1,5 ... 2,5
	Stripping length	mm	7
	Tightening torque	Nm	0,5
Maximum power consumption	W	10	

11 Inputs and outputs

Characteristic	Unit	Value	
Voltage measurement inputs			
Rated voltage N-Ph	V	58 ... 300, RMS	
Rated voltage Ph-Ph	V	100 ... 500, RMS	
Rated voltage max., with respect to earth	V	300	
Rated frequency	Hz	10 ... 200	
4-pole terminal block	Quantity	Piece	2
	Stranded wires 16-12 AWG	mm ²	1,5 ... 2,5
	Stripping length	mm	7
	Tightening torque	Nm	0,5
Measurement category	-	CAT III	
Overvoltage category	-	CAT III 300 V	
Current measurement inputs			
Only to be used with Schaeffler current transformers/Rogowski coils			
Number of connections	-	2× 3-phase	
Connections	-	RJ45	
Rated voltage, differential	mV	333	
Maximum voltage, differential	mV	426	
Sensors: Current transformers (CTs) or Rogowski coils	-	Set with 3 sensors	

Characteristic	Unit	Value
Measurements		
-	-	In accordance with standard IEC 61557-12 Active energy index CEI 62053-21 Class 1 (1 %) Reactive energy index CEI 62053-23 Class 2 (2 %) Frequency
Measured variables	-	Ip, VpN, Up-p, Pp, Ptot, Sp, Stot Qp, Qtot, PF (vector) Voltage unbalance, current unbalance Voltage dips, voltage rises THDu, THDi

12 Interfaces

Characteristic	Unit	Value	
Ethernet connectivity (reserved for future use)			
Number of connections	-	2	
Connection	-	RJ45	
Overvoltage, max.	kV	1,5	
Standard in accordance with IEEE 802.3	-	10/100 Base-T	
Wiring	-	Auto MDI/MDIX	
RS485 interface (reserved for future use)			
3-pole terminal block	Quantity	Piece	1
	Stranded wires 25-16 AWG	mm ²	0,14 ... 1,5
	Stripping length	mm	7
	Tightening torque	Nm	0,25
Signal level	V	0 ... 5 (A-B)	
	V	-7 ... 12 (GND-A/B)	
Common-mode voltage isolation, max.	kV	1,5	
Rate	kbps	9,6 ... 115,2	
Supported protocols	-	Modbus RTU	
Wireless connection			
Antenna	Ω	External 50	
Connection	-	SMA	
Protocol	-	LTE Category 1	
Frequency bands	LTE-FDD	-	B1/2/3/4/5/7/8/12/13/14/18/19/20/25/26/28
Wi-Fi connection			
Antenna	-	Internal	
Protocol in accordance with IEEE 802.11	-	b/g/n	
Frequency	GHz	2,4	
Mode	-	Access point	
Security	-	WPA2 authentication AES encryption	
LEDs			
-	-	Status	
-	-	Connection	

10.3 Type plate

The nameplate with the serial number (S/N) is located on the left-hand side of the housing.

The serial number is also encrypted in the applied Data Matrix code.

10.4 Abbreviations for measured values

☐13 Measured values

Abbreviation	Description	Unit
I_p	Current per phase	A
V_{pN}	Voltage phase to neutral conductor	V
U_{pp}	Voltage between the phases	V
P_p	Active power per phase	W
P_{tot}	Total active power	W
S_p	Apparent power per phase	VA
S_{tot}	Total apparent power	VA
Q_p	Reactive power per phase	VAR
Q_{tot}	Total reactive power	VAR
PF	Power factor (0...100) (P_{tot}/S_{tot})	%

11 Declaration of Conformity

Certificates

The full text of the EU Declaration of Conformity and other certificates are available at the following Internet address:

EN: www.schaeffler.de/en/technical-support

DE: www.schaeffler.de/technischer-support

11.1 Declaration of Conformity

11.1.1 FCC Statement

FCC 15.21

The company "Eco-Adapt SAS" is not responsible for any changes or modifications that were not expressly approved by the regulatory authority responsible for compliance. Such modifications may invalidate the operating permit for the device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference and
- this device must accept any interference received, including interference that may cause unwanted operating states.

FCC 15.105

NOTE:

This device has been tested and found to comply with the limits for Class A digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the device is operated in a commercial environment. This device generates, uses and can emit high frequency energy. If it is not installed and used in accordance with the operating manual, interference may affect wireless communication. Operation of this device in a residential area may cause interference. In this case, users must rectify the interference at their own expense. This device must be installed by a specialist.

11.1.2 ISED Declaration of Conformity

This device contains one or more licence exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept all interference, including interference that may cause unwanted operation of the device.

This device complies with ISED RSS-102 radio frequency exposure limits that were defined for an uncontrolled environment under the following conditions:

- This device should be installed and operated in such a way that a minimum distance of 20 cm is maintained between the emitter (aerial) and the body of the user/persons nearby at all times.
- This transmitter must not be installed or operated in combination with any other aerial or transmitter.

12 Manufacturer details

Eco-Adapt SAS
28 Rue de Châteaudun
75009 Paris
France
www.eco-adapt.com 

Schaeffler Technologies AG & Co. KG

Georg-Schäfer-Straße 30

97421 Schweinfurt

Germany

www.schaeffler.de/en/services

Technical support:

www.schaeffler.de/en/technical-support

All information has been carefully compiled and checked by us, but we cannot guarantee complete accuracy. We reserve the right to make corrections. Therefore, please always check whether more up-to-date or amended information is available. This publication supersedes all deviating information from older publications. Printing, including excerpts, is only permitted with our approval.
© Schaeffler Technologies AG & Co. KG
BA 139 / 01 / en-GB / 2026-04